



E Series Installation

Using Adhesive Tape

(with fixer backup if necessary)

1

Tools required

- Methylated spirits
- Glue gun
- Glue
- Roller
- Brush and pan
- Paint scraper
- Soft cloth
- Concrete Screws
 - 8 x 32mm (1 1/4 inch) countersunk square (#1) Stainless Steel AB self tapping screw.
- Anchor – 6mm x 30mm (0.25 x 1 3/16 inches) plastic anchor



2

Preparation of surface

- Clean all loose and flaking material from surface using tools and cleaning agents as necessary to ensure a clean dry and oil-free contact surface.



3

Alignment (for installation to more than one step)

- Mark 50mm (2 inches) from the edge of the top step
- Mark 50mm (2 inches) from the edge of the bottom step
- Place a line between the marks to ensure the ecoglo strip on each step will be correctly aligned
- **NOTE:** The maximum recommended length for installation in outdoor situations is 1.5 metres (5 foot), with a minimum 5mm (1/8th inch) gap between lengths. This allows for thermal expansion in extreme weather conditions and also aids in water drainage off the step tread.



4

Installing the strip

- Carefully peel off the backing to the adhesive tape from the E series strip.
- Carefully place the strip in position on your step using the line to ensure correct alignment with other steps. The glow strip should be to the front edge of the step.



5

Press firmly in place

- Press the strip firmly in place to ensure even contact between the adhesive tape and the surface of the step, using a roller or your feet.



6

Low adhesion

- If in doubt about the adhesion of your strips, use concrete nails for additional security



7

Drill holes for fixers

- Using the pre-punched holes in the strip as a guide, drill an appropriate sized hole in the concrete to suit your concrete nail or fixer



8

Clean fixing hole

- Brush away dust from fixing hole



9

Insert fixer

- Place a concrete nail or appropriate fixer in each hole and drive fully home



10
