



## Threshold Strip Installation Guide

### Preparation of Surface

- Ensure the mounting surface is clean of dirt, dust and debris.
- If a sealant has been applied to the concrete steps we recommend contacting your local adhesive representative to check compatibility.



## Alignment (for installation to more than one step)

- Place one piece of step nosing on the top step and one on the bottom step.
- Run a string line from the left edge of the top nosing to the left edge of the bottom nosing.
- This will give you a straight, true line.
- **NOTE:** *The maximum recommended length for installation in outdoor situations is 1.5 metres, with a minimum 5mm gap between lengths. This allows for thermal expansion in extreme weather conditions and also aids in water drainage off the step tread.*



- Using a cartridge glue gun apply a 1/8 inch bead of the recommended polyurethane adhesive in a weaving pattern along the full length of the underside of the nosing
- **Note:** *Ecoglo New Zealand installations use Bostik Seal n Flex FC. Expected usage of adhesive is: 28 metres per 600ml sausage.*



- Turn the Ecoglo strip back to right side up and press on to the step.
- Apply downward pressure to ensure a good bond along its full length.
- If any adhesive squeezes out around the edges, wait until it cures before removing by trimming off with a box-cutter type cutting blade.
- Immediately following installation close off the area for a period of 2-3 hours to avoid the Ecoglo strip being moved whilst the adhesive is in the early stages of "cure".

